




CABLE, FREEZER DOOR
PN - 19100081A



CABLE, UP / DOWN
PN - 19500480A




COMPUTER BOARD
PN - 19300527A



DEADWEIGHT ASSEMBLY
PN - 19510119A




DIGITAL DISPLAY BOARD
(AFTER SN-8018)
PN - 1919300521A



GEAR W/ HOLE
PN - 19500406A



HEALTH SWITCH ASSY
PN – 19500582A




KEYPAD INSERT
PN – 19300571A




MENU HOLDER, 12-CARD
PN – 19380127A



MOTOR 115V
PN – 19900555A




OPTO ENCODER DISK
PN – 19500492A



OPTO ENCODER DISK/GEAR
PN – 19510153A



OPTO ENCODER DISK/REEL
PN – 19510117A



OPTO ENCODER SWITCH
PN – 19500582A



PICKER TUBE ASSEMBLY
PN – 19510113A



POWER BOARD
PN – 19300530A




REED SWITCH, MAGNETIC
PN – 19900518A



REED SWITCH, UP/DOWN
PN – 19500515A



RIBBON CABLE
PN – 19510300A



SLACK SWITCH
PN – 1919500566A



THERMOMETER
PN – 19600738A



THERMOSTAT
PN – 19600513A



VACUUM PRESSURE SWITCH
38" (TOP)
PN – 19500557A



VACUUM PRESSURE SWITCH
48" (BOTTOM)
PN – 19200558A